



Installation Criteria when using AP130.10 3SIXTY anchors on metal clad roofs containing Roof-Spacer:

- Maximum 150mm spacer can be used
- Minimum of 4 cladding sheets must form the surface of the roof
- Minimum of 3 purlin bays (4 purlins) must form the surface of the roof
- Minimum of 2 cladding sheets must be on either side of the anchor
- 2 x 14G screws fasteners through roof sheet into Roof-Spacer bar + Qty 8 x 8mm Gesipa Rivets. Note: Any 2 opposite holes can be used to attach to bar member.

NOTES

- THIS ANCHOR MUST BE INSTALLED ACCORDING TO INSTALLATION MANUAL
- FOR RIVET ONLY INSTALLATION CRITERIA - REFER TO INSTALLATION MANUAL