



**Installation Criteria when using AP141 Abseil anchors on metal clad roofs containing Roof-Spacer:**

- Maximum 150mm spacer can be used
- Minimum of 4 cladding sheets must form the surface of the roof
- Minimum of 3 purlin bays (4 purlins) must form the surface of the roof
- Minimum of 2 cladding sheets must be on either side of the anchor
- 3 x 14G screws fasteners through roof sheet into Roof-Spacer bar + Qty 9 x 8mm Gesipa Rivets.